


Montageanleitung für Rohrschutzbügel

Fitting Instructions for guard tube

Notice de montage pour arceau de sécurité



ZA-M 900



10 x 6KT-SHR M10 x 25

10 x 6KT-MU M10

10 x SHB 10,5

4 x Stopfen