













AMAZONE

Montageanleitung für Bausatz

ZA-M Ultra

-  FL-RD M8 x 16 (9 STK)
-  6KT-SHR M8 x 35 (7 STK)
-  6KT-SHR M8 x 20 (4 STK)
-  SI-MU M8 (24 STK)
-  SHB (54 STK)
-  6KT-SHR M10 x 55 (2 STK)
-  6KT-SHR M10 x 70 (4 STK)
-  6KT-SHR M10 x 30 (10 STK)
-  SI-MU M10 (16 STK)
-  Flügelmutter (1 STK)

