

Centaur 4000 / 5000 Special/Super

Kurz - Betriebsanleitung

(D)

Steuergerät	1	Maschine ausklappen	1 x blau	Schlauchmarkierung
		Maschine einklappen	2 x blau	
2	Arbeitstiefe vergrößern	1 x grün		
	Arbeitstiefe verkleinern	2 x grün		
3	Maschine absenken	1 x gelb		
	Maschine anheben	2 x gelb		

von Transport- in Arbeitsstellung

1. Steuergerät 3 (2 x gelb) + Traktorhubwerk:

- Maschine komplett anheben.

2. Steuergerät 1 (1 x blau):

- Seitenrahmen vollständig ausklappen.
- Mittelwalze absenken.

Kombinierte Funktion, Steuergerät länger betätigen!

3. Steuergerät 3 (1 x gelb) + Traktorhubwerk:

- Maschine in Arbeitsstellung absenken..

Vorgewende

Steuergerät 3 (2 x gelb) + Traktorhubwerk:

- Maschine vollständig anheben.

von Arbeits- in Transportstellung

1. Steuergerät 3 (2 x gelb) + Traktorhubwerk:

- Maschine vollständig anheben.

2. Steuergerät 1 (2 x blau):

- Maschine vollständig zusammenklappen und seitliche Walzen ganz einfahren.

Kombinierte Funktion, Steuergerät länger betätigen!

3. Steuergerät 3 (1 x gelb) + Traktorhubwerk:

- Maschine bis auf maximal 4m Transporthöhe absenken!

MG1447

Quick manual

(GB)

control valve	1	folding down	1 x blue	Hose marking
		folding in the machine	2 x blue	
2	increase working depth	1 x green		
	reduce working width	2 x green		
3	Lower the implement	1 x yellow		
	Lifting the implement	2 x yellow		

from transport to operating position

1. control valve 3 (2 x yellow) + tractor hitch:

- Lift the machine completely.

2. control valve 1 (1 x blue):

- Fold down the side frame.
- Lower the centre roller.

combined function, actuate control valve longer!

3. control valve 3 (1 x yellow) + tractor hitch:

- Lower the machine in operating position.

Headlands

control valve 3 (2 x yellow) + tractor hitch:

- Completely lift the machine.

from operating to transport position

1. control valve 3 (2 x yellow) + tractor hitch:

- Completely lift the machine.

2. control valve 1 (2 x blue):

- Fold in the machine completely and swivel in the lateral rollers completely.

Combined function, actuate control valve longer!

3. control valve 3 (1 x yellow) + tractor hitch:

- Lower the machine to maximum 4 m transport height!

